

Interclad[®] (uk) Ltd

walls floors ceilings

OFFICES AND ACCOUNTS

173 Main Road

Biggin Hill, Kent TN16 3JR

Telephone: 01959 572447

Fax: 01959 576974

sales@interclad.co.uk www.interclad.co.uk

This wall finish is

MEDICLAD

and this notice is important

There is not a problem fixing shelves – or anything else – to the Caterclad wall finish providing the following steps are taken.

THE INITIAL HOLE MUST BE DRILLED WITH A HSS DRILL USING LIGHT PRESSURE AND ENSURING IT IS OVERSIZE TO THE FIXING BEING USED.

A HARD TIPPED DRILL CAN THEN BE USED ON THE SUBSTRATE.

ANY RAWPLUG USED MUST BE PUSHED INTO PLACE – NOT HAMMERED.

DO NOT OVER-TIGHTEN THE FIXING BEING USED.

CLEANING INSTRUCTIONS

WIPE DOWN WITH A SOFT CLOTH USING WARM/HOT WATER AND SANITIZER.

DO NOT USE ANY FORM OF ABRASIVE CLEANER – EVEN THOSE THAT DO NOT SCRATCH.

SOAP CAN BE USED BUT AS IT MAY LEAVE A 'FILM' ON THE CATERCLAD, IT SHOULD THEN BE WASHED OFF AGAIN USING WARM/HOT WATER.